

Sovol SV01 Firmware Recovery

```
"C:\Program Files (x86)\Arduino\hardware\tools\avr\bin/avrdude" -  
C"C:\Program Files (x86)\Arduino\hardware\tools\avr/etc/avrdude.conf" -v -  
patmega2560 -cwiring -PCOM1 -D -  
Uflash:w:C:\Users\mchus\Downloads\Marlin_2.0.5.3-Sovol_SV01-1.6.3-  
SilentBoard_BLTouh_en.hex:i
```

From:

<https://micronode.ru/> - **micronode.ru**

Permanent link:

https://micronode.ru/wiki/3d_print/problem/sovol_firmware_recovery

Last update: **2023/01/11 06:10**

