

How to Launch MPC Panel on a Gx00 SVP

Symptom

- MPC is not available and System Option Mode needs to be changed

Environment

- Hitachi Virtual Storage Platform Gx00 (VSP Gx00), HM800

Resolution

Note: These are not supported options.

Method 1

1. Create an empty text file named MPC.INI in the C:\Mapp\wk\Supervisor directory.
2. Reboot the SVP and Login back in as SVP.
3. Once you have finished your MPC operations - delete the C:\Mapp\wk\Supervisor\MPC.INI file and reboot the SVP to put it back into its normal mode.

Method 2

Launch **zSv_Svp_main** from **C:\Mapp\wk\<serial number>\DKC200\mp\pc** directory

Additional Notes

Please note that running the SVP in MPC mode is not supported and should not be used.

[vsp gx00](#), [vsp fx00](#)

From:
<https://micronode.ru/> - **micronode.ru**

Permanent link:
https://micronode.ru/enterprise/hitachi/solutions/run_mpc_on_svp

Last update: **2021/02/02 18:30**

