

IMM CLI

Server Console

Start the SP console

```
start /SP/console
```

See the currently active sessions

```
show /SP/sessions
```

Stop any user session

```
stop /SP/console
```

SP Console

Boot

boot from cd-rom

```
boot cdrom
```

Obtain the OpenBoot Prompt (Oracle ILOM CLI)

```
set /HOST/bootmode script="setenv auto-boot? false"
```

From:

<https://micronode.ru/> - **micronode.ru**

Permanent link:

<https://micronode.ru/enterprise/sun/guide/imm>

Last update: **2024/01/03 12:12**

