


# Prusa Slicer / Slic3r / Super Slicer


## Unwanted Solid Infill

### Problem:




### Solution:

- Increase “Solid infill threshold area”
- Decrease to 0 “Anchor solid infill by X mm”



### Result:



From:

<https://micronode.ru/> - **micronode.ru**

Permanent link:

[https://micronode.ru/wiki/3d\\_print/problem/prusaslicer](https://micronode.ru/wiki/3d_print/problem/prusaslicer)Last update: **2023/01/11 06:19**